



# HP Stream 8 Midframe Replacement

This guide will walk you through the steps of replacing the midframe of you HP Stream 8 if it is cracked or damaged.

Written By: Nick Miller



## Step 1 — Midframe



- Use your nail or a spudger to pry up the back cover of the device.

## Step 2



- Slide your finger around the rest of the back cover, lifting it completely off of the device.

### Step 3



- Remove all ten of the screws on the inside cover using the screwdriver with a PH00 Phillips head.

### Step 4



- Pry up the inside cover the same way as in the first step.

To reassemble your device, follow these instructions in reverse order.